





DUTZO C730 Mesh TG RGB

[operating manual]
















Back view




Left view(open side panel)




Right view(open side panel)




The bottom view






Metal side plate installation: buckle the side plate and fix it with two screws




The power supply can be fixed by aligning the screw in the figure to the hole position


Note: different types of power supply, hole location may be slightly different, take the actual object as the standard.




According to the motherboard model, Main board screws are used for fixing copper column should be replaced manually Support E-ATX/ATX/M-ATX/Mini-ITX









Remove the front panel of the case and open it by hand in the lower direction



Front: 3 x 120mm fan(included) Rear:1x 120mm fan(included) Top:2 x 120 /140mm fan(optional)



WaterCooling System:Front:1 x 240/360mm Top:1 x 240mm Rear:1 x 120mm



2.5 SSD x 2

Align the SSD with the screw hole and fix it with screws




3.5 HDD x 2

Push the hard disk into the hard disk rack and secure it with screws



NOTE: The PCI slot can be horizontal and can be mounted vertically



The PCI slot mounted horizontal

NOTE: The PCI slot can be horizontal and can be mounted vertically